

MSK-160D & MSK-160D1

ELECTRIC COIN CELL CRIMPER & DE-CRIMPER

For CR20XX Button Cells



CRIMPING AND DE-CRIMPING DIE INSTALLATION




860 South 19th Street, Richmond, CA 94804, USA
TEL: (510) 525 – 3070 FAX: (510) 525 – 4705
Website: www.mtixtl.com Email: info@mtixtl.com

MSK-160D CRIMPING DIE INSTALLATION



1. Upper Die Assembly



Once the upper die has been fully assembled, insert it into the top plate of the MSK-160D as shown and tighten the set screw.



2. Lower Die Assembly



Complete the installation of the lower die by inserting its base into the opening of the MSK-160D's lift plate as shown:



MSK-160D1 DE-CRIMPING DIE INSTALLATION

Please refer to the pictures below to distinguish the de-crimping die components from those of the normal crimping die set.





Lower Die




Upper Die

3. Upper Die Assembly (De-Crimping)



Secure this upper die set into the top plate of the MSK-160D1 and proceed to the lower die assembly.

4. Lower Die Assembly (De-Crimping)



Insert this lower die into the opening of the MSK-160D1's lift plate to complete the installation:

